

## P51 Daughter Board Installation

1. Flip the P51 so that it is facing screen down. Insert the AUX fittings provided in ports A1, A2, T1 and T2 to hold the black washers.
2. Using a T10 torque screwdriver remove the 4 screws in the casing and remove the back cover.
3. Remove the broken daughter board by easing it from the main circuit board. Install the black washer from the old daughterboard onto the new one and secure them with the AUX fitments.
4. Put the blue modification on the blue modification provided over the USB micro B port. Note – this modification may already be on the port.
5. Install the daughter board into the terminal on the motherboard.
6. Place the back cover back on insuring that the black washer on the hook is in the gap separating the casings as well as the grey grips on each side.
7. Screw the casings back together. Remove the AUX fittings. Plug unit in for charging. If unit does not charge repeat from step one.