# **FixQuick**

## Ultra-fast UV Fluorescent Leak Stop

## **Product Description**



FixQuick is the new ultra-fast leak stop by Errecom, specifically formulated to repair in max 30 seconds leaks up to 1 mm in diameter on flat and curved surfaces. It guarantees a seal up to 50 Bar (725 PSI) pressure and 250°C (480° F). It can be used on metals and plastic components of AC/R systems. Its fluorescent formulation allows to easily check the status of the performed fixing using a UV lamp and to identify any previous repairs.

Laboratory tests have confirmed a further application of FixQuick: it can be used to successfully seal leaks in radiator cooling systems.

### Features

- Formula Step1+Step2+Step1= easy to use.
- 20 seconds to repair the leak that can withstand a pressure of 20 Bar (290 Psi).
- 20 minuts to repair the leak that can withstand a pressure of 50 Bar (725 Psi).
- It resists up to 250°C (480° F).
- It is visible with UV lamp.

## **Use Instructions**

Apply the product on a surface perfectly dry and clean. It is recommended to clean the area with sandpaper. Remove any residuals that could affect FixQuick performance.

Apply the STEP 2 powder on the surface

just treated creating a thin layer.



Apply the **STEP 1** liquid product on the leaking area and the around surface wihout pressure.





Apply once again the **STEP 1** liquid product to obtain a homogeneous reparation.



30

Before placing the brush back into the STEP1 container, clean it thoroughly so that any STEP2 powder residue is removed. Wait 20 seconds to obtain a repair that can withstand a pressure of 20 Bar (290 Psi) or 20 minutes (at 20°C -standard room temperature-) for a repair that withstand a pressure of 50 Bar (725 Psi) and 250°C (480°C).

## Packaging



10 g bottle STEP 1 and 5 g bottle STEP 2 in carton box

Display with 30 carton boxes.



Packaging made in carton box 100% recyclable.

**Danger Indications** 



#### Warning

Hazard statements: H315 Causes skin irritation. H319 Causes serious eye irritation. H335 May cause respiratory irritation.

**Precautonary statements:** P302+P352 IF ON SKIN: Wash with plenty of water. P337+P313 If eye irritation persists: Get medical advice/attention.

**Special Provisions:** EUH202 Cyanoacrylate. Danger. Bonds skin and eyes in seconds. Keep out of the reach of children. **Contain:** ethyl 2-cyanoacrylate

STEP 2 No indication of danger.

Professional usage product: wear the appropriate protective uniform. Read the instructions on the label carefully.



Art.-Nr. TR1241.01